Multifunction 3D Pedometer USB flash disk

Time
Calorie
3D Pedometer
USB Flash Disk

Instruction Manual Version 1.0

Hello

Thank you for choosing our products!

In order to let you handle this product freely and easily as soon as possible,we randomly come with a detailed user manual. You can obtain information about the product introduction,using methods and so on. Before using this product, please read all the information we have supplied carefully,so that you could use this product better.

We are very serious and rigorous when writing this manual, hope to provide you with complete and reliable information. However,it is hard to avoid errors and omissions,thanks for your understanding and sincerely welcome your comments and corrections. If you find any problems during usage, please call our service hot line. Thanks for your support and cooperation!

Please back the data information to your computer at any time. Our company will not be responsible for the loss or damage to the personal information caused by mis operation to software or hardware, product repair,or other unexpected. And we will be also not in charge of the other indirect loss caused by our products. While we have no control over the misunderstanding to the manual of the user, so our company will not be responsible for the unexpected loss during usage,and we will also not be in charge of the claims from the third party caused by our products.

If there is any change of information in this manual without prior notice.

This manual is protected by copyright, without our company's prior written permission,any part of it could not be photocopied or copied in any way. Our company reserve the right to the manual,Three Guarantees Certificate and the power for the final interpretation to the related information.

Notice

◆Prohibit children to play with this machine alone. Please don't fall off or rub and strick with hard object, otherwise, it may cause abrasion to the machine's surface,data loss or other damage to hardware.

◆Please don't heat the battery or put it into the fire.Lithium Battery Meltdown,will have a violent rupture,causing a fire.

◆Please don't attempt to break down or modify this machine,this can result in electric shock or hinder the product warranty.

◆Don't use chemicals or cleaning kit to clean the machine,which will damage machine surface and corrode paint.

◆This product is waterproof design for daily life. Don't let it soaked in water, against wearing it when taking a shower or swimming.

◆When the product is used as a portable hard drive, please store or derive files with correct file management way. Our company will be not responsible for any file lost caused by any action.

◆Suggest to backup the personal information stored in this machine in time.

◆Forbid this product using the overload power charging,bending forcibly or squeezing heavily the strap. It may cause fires.

◆Please don't expose this machine to the humid environments or in the rain.. If the device is water or damp, it may lead to equipment failure and even be unable to repair.

◆This product has built-in lithium battery. Please charge it on a regular basis in order to ensure they are working properly.

◆Because of performance and function of this products changes without prior notice,please understand.

◆If the actual product due to firmware upgrades such as setting up and using methods inconsistent with this manual, please check with the dealer to obtain the latest product information.Thank you for your cooperation!

Product Brief Introduction

●Built-in 3D acceleration sensor with high sensitivity,can catch your each small action,Making more accurate pedometer.

●It can trace your burning calories,movement steps,movement distance,and also could set and inquire the complete of moving goal.

●Set USB 2.0 interface as a whole one,Plug and Play. Built-in large capacity storage space can be used as a removable hard drive.

●With the memory function of movement data,could record and view the one's movement data for more than 10 years.

●Display time/day,adjust time with the computer synchronization.

●USB rechargeable watch,built-in rechargeable battery,connected to the USB port to store data and charging.

●Small body, Light weight, Simple and Stylish, easy to wear.

Appearance Notes



1.USB Port
2.LED display Screen
3.Soft touch key

Adorn correctly

Hanging around your neck

put it in the bag

put it in your pocket

Basic operations

1.Watch time/day: short press button to display the current time and date.

【Hint】: The introduction of the key functions on this page are all under the sleep state of the products to press buttons.

2.Enter into the pedometer: long press the button for 3 seconds to enter into pedometer state.

【Hint】:

①When the pedometer,short press buttons to switch step counter or timer job status.

②While the step counter or timer,press buttons for 3 seconds to quit the current working status.

3.Set the time:

①Short push the button to enter into the current live status to display time.

②When the time screen is displayed, long press the button for 3 seconds to enter into the time adjustment mode.

【Hint】: ①When entering into adjustment time state,short pushing the button is numerical increase, long pushing the button for 3 seconds is to switch adjustment options.

②Setting time could also be synchronized over a computer. (Please refer to page 9)

Communication Operation

1. Connect Computers

①Connect the USB port of this machine to the computer's USB interface, and then the screen will display USB connection Status.

②If it is the first time to use this machine, Windows will show "Found new hardware".

③It will show a new disk in "MY COMPUTER".

2. Break the connection to the computer.

①Before removing this machine from the computer, please make sure that the communication with the computer has been stopped. You must be properly uninstall the USB device, or it may cause damage to or loss of data.

②Double - click the computer in the lower right corner of the " unplug or eject hardware ", such as the right.

③Click on "STOP" in the pop-up window.



④Then click on "OK" in the pop-up window, you can move away the USB cable.

The above pictures are subject to the actual operations!

Illustration of software function

This product has random matching software， set personal information,track your burning calories,moving steps and movement distance,and could also set and inquire the complete of your moving goal.

1.Set of personal basic information



【Hint】:Please set correct personal information,so that the machine could more accurately track your burning calorie, moving steps and moving distance.

2.Time set of PC



【Hint】

①After clicking "Execution time correction",please remove the device from the computer immediately,the machine will correct time automatically.

②Factory-set default display time is 24h system. It can set up as 12h system.

③The progress bar of Time Set Column is used for fine tune adjustment of timing error. If the time is correct,please don't adjust this item.

3.Mission/target



【Hint】

①You can set and inquire the complete of your exercise goal on this page.

②Please click start after setting goal. The next exercise data will be added up to your set target.

4.Report



【Hint】

① You can trace your burning calorie,movement steps and movement distance on this page.

②You can click "Month Report" or "Day Report" to check data information of the current month or current day.

③You could click the "calendar" in the right corner of the software interface to select the day you want to check.

5.Career

【Hint】

①You can trace your accumulative burning calorie, movement steps and movement distance on this page

②After clicking "Reset/Zero", the accumulated data will be zeroed on this page.

6. User Option：

【Hint】

①You can set on this page whether to start the program update checking and program automatic update function.

②If the user checks off the two software options on this page,when there is new version program,the software will automatically update to the new version.

Specification parameter

Boundary dimension	70mm×20mm×10mm(Specific please in kind prevail）
Weight	13g（net weight）
Display screen	LED Lattice Screen
Capacity	1G/2G/4G/8G/16G/32Gelse（Specific please in kind prevail）
Interface type	USB2.0
Step count accuracy	±5%
Time error	24H error(The software can adjust the rage ±99 secs/day）
Data memory	Memorize over ton-year exercise data
Display of steps	Max 9999 steps displayed on the screen; Max 65535 steps recorded by the software recorded by the software
Battery life	Rechargeable battery，charge-discharge times>300times
Supply voltage	DC=5V
Run barometric pressure	860 hPa ～ 1060 hPa
Operating temperature	0 to 45 degrees centigrade

If there are any change due to improvements of specifications and appearance,without notice.